## Rainier Commons Exterior Paint Abatement Project Interior Space Assessment, Protection, And Inspection Checklist

SET-UP NUMBER	_ BUILDING	UNIT NUMBER	
Prior to NPE Installation			
Verify removal of all tenant-ins to planned blasting operations		ocks, pictures, curtains, etc.) on wall adjac nitials	ent
plastic across windows, as nee	ded for light control. Allowaces to identify any exterio	erior walls subject to abatement. Utilize by time for vision to adjust to lower light lear by light entering the interior space. Plug a	vel.
Disable heating system by de-efurnace. Initials	energizing the circuit break	er and removing the front panels on the	
Disconnect clothes dryer vention 4-mil polyethylene sheeting, se	=	or wall. Cover vent opening with two laye ials	rs of
Disable kitchen and bathroom breaker and unplugging the ap		side (VTOS) by de-energizing the circuit itials	
		as described in Work Plan. 4-mil d spray adhesive, as needed. Initials	
Install signage at entry of inter authorized personnel only. (No	•	entry to protected area restricted to  Is	
Provide a UV HEPA air purifier protective barriers, for tenant		de tenant space, but outside interior	
Ensure windows remain closed	I and locked until final clea	rance is received. Initials	

## Rainier Commons Exterior Paint Abatement Project Interior Space Assessment, Protection, And Inspection Checklist

SET-UP NUMBER	BUILDING	_ UNIT NUMBER
<b>During Abatement</b>		
barriers, paying careful attent actions, or any other causes, of and/or spray adhesive with ac	ion to possible rips and tea during non-blasting times/c Iditional poly used for patc	ough inspection of all interior protective rs in the barrier poly, resulting from tenant lays. Damage to be repaired with duct tape h materials. All existing adhesive joints shall notate completion in Daily Field Notes.
Periodically during active blas spaces, to ensure proper oper		rity verification inspections of interior tenant re.
barriers, paying careful attent	ion for the presence of any d, perform the testing and	thorough inspection of all interior protective visible dust within or nearby the containment cleaning protocol shown on the Rainier Flowchart.
To provide a daily visual indicated access door, as follows:	ator of each unit's access st	atus, door tags will be hung on each unit's
Green Door Tag – Unit cleared	I for tenant access	
Red Door Tag – Unit not clear	ed. Tenant access not allow	ved.
Post-Abatement		
Obtain post-abatement cleara structures. See Observation a	•	o initiate removal of interior protective NVL signature.
•	•	ary interior barrier, carefully rolling the side bag for proper classification and disposal.
Inspect exposed interior wall a	area for any signs of foreign	objects (sand, dust, streaks). Initial
Take down secondary interior	barrier and place in garbag	ge bag for proper disposal. Initial
Clean, HEPA vacuum, and dus containment area. Initials		previously located along the interior
(NVL to obtain post-abatemer	nt wipe samples per sampli	ng plan)

## Rainier Commons Exterior Paint Abatement Project Interior Space Assessment, Protection, And Inspection Checklist

SET-UP NUMBER	BUILDING	UNIT NUMBER		
Restore heating system. As a courte	esy, install new furnace air fi	lter(s). Initials		
Reconnect clothes dryer venting and kitchen and bath fans. Initials				
Custodial Service to perform courtesy house cleaning of remaining unit. Initials				
Remove HEPA air purifier Initials				